




# Eco Roll-up Banner Display



**IMPORTANT - Do NOT remove the Locking Pin until shown.**


**1 Fitting top of Banner to Top Rail**

i) Peel 100mm of protective strip from the Top Rail. With the image face side **downwards** attach one corner of the Banner to the Rail.  
 ii) Hold the Banner in line while gently removing the remainder of the protective strip.




**2 Fitting bottom of Banner to the Box 'Apron'**

Remove the protective strip from the tape on the Apron. Follow the printed black line & apply the Banner with the image face side **upwards**.  
 (Use a strip of low tack self adhesive tape, Selotape or similar, to hold down the bottom edge of the Banner).



**3 Loading the Banner**

i) Hold the Apron against the Box with your left hand. Slowly remove the Locking Pin. ii) Hold the Banner at the sides & guide it while it retracts into the Box.

Place Locking Pin here for safe keeping.





**4**

i) Rotate Feet.


ii) Stand on Feet.

iii) Place the Pole into the Hook in the Top Rail & into the Hole in the Box.

iv)

Rear view of Eco Roll Up Banner.



Although this is generally a one banner display/storage system, banners can be changed by removing the low tack tape, cutting the 'apron' and banner top to remove adhesive join and applying new strips of double-sided tape to both. This is the reason for the printed positioning line on the apron being away from the edge of the apron.